

**Weekend Operations At Easter Airfield - Inbound Aircraft**  
**Fridays 1400 hours Local to 0800 hours local Mondays**

1. Obtain PPR by calling Dickie Bird on 01862 871555 or 07973 851944 (email mauk@btconnect.com) or David Munro on 01862 832900 or 07967 715304 (email dhmunro@btconnect.com)
2. Route to E/E Lane Nigg Bay.
3. Call "Easter Radio" on 122.750.
  - a) If manned you will receive the runway in use, wind direction & speed and QFE. The norm is a straight in approach for RWY 06 or downwind, right hand for RWY 24. However, if you prefer, please feel free to make a standard overhead rejoin.
  - b) If not manned, continue to transmit blind on Easter Radio 122.750.

**PLEASE DO NOT FLY OVER THE WHITE BUNGALOW!**

**Weekend Operations At Easter Airfield - Outbound Aircraft**  
**Fridays 1400 hours Local to 0800 hours local Mondays**

1. If manned call "Easter Radio" on 122.750 for runway in use, wind direction & speed and QFE. (If unmanned, transmit "blind" on 122.750).
2. Taxi for power checks.
3. Depart RWY 06 LH or 24 RH depending on wind direction.
4. Depart the Easter circuit for E/E Lane Nigg Bay, in accordance with the noise abatement procedures.

**If RWY 06 is in use, an early left turn is always appreciated but:**

**PLEASE DO NOT FLY OVER THE WHITE BUNGALOW!**